



No.	Part Name(Chinese)	Part Name(English)	Code	Qty	No.	Part Name(Chinese)	Part Name(English)	Code	Qty
1	防尘罩	Dust Cover	10102004107	1	45	气缸	Cylinder	10306004002	1
2	防尘罩卡簧14×1.5	Ring Spring 14×1.5	30303007	1	46	气缸销垫片	Washer	30403009	2
3	防尘罩垫片16×22×1.6	Pad 16×22×1.6	30403020	1	47	气缸销	Piston Joint	30701002	1
4	卡套卡簧18.5×2	Ring Spring 18.5×2	30303010	1	48	支架O形圈50×8	O Ring 50×8	10102003211	1
5	卡套	Chuck Cover	10101009019	1	49	支架衬套	Stand Bush	10306002018	1
6	卡套垫片21×32×4	Washer 21×32×4	30403031	1	50	支架	Stand	10209004003	1
7	钢球7.14	Steel Ball 7.14	30603011	1	51	支架压叉	Stand Fork	10306005013	1
8	卡套花垫片	Flower Washer	30403093	1	52	O形圈23.5×2.5	O Ring 23.5×2.5	10102003032	1
9	锥形弹簧	Cone spring	10303001031	1	53	轴承609	Bearing 609	30103189	1
10	钻套	Cylinder	10306002019	1	54	609轴承压板	Bearing Cover	10305001075	1
11	钻套O形圈21.5×1.8	O ring 21.5×1.8	10102003046	1	55	沉头自攻锁紧螺钉M4×10	Screw M4×10	30201159	2
12	油封8×16×5	Oil Proof Seal 8×16×5	10102003005	1	56	中间轴	Middle shaft	10301003003	1
13	锤杆限位圈	Spacing Collar	10306002015	1	57	轴承699	Bearing 699	30103129	1
14	锤杆	Impact Bolt	10306005012	1	58	调档拨叉	Shift Switch	10401005002	1
15	自攻螺钉ST4×40	Screw ST4×40	30202042	4	59	调档拨叉卡簧	Ring Spring	30303004	1
16	头壳	Gear Box	10101011019	1	60	滚针轴承HK0908	Needle Bearing HK0908	30101017	1
17	油封30×41×7	Oil Proof Seal 30×41×7	10102003004	1	61	摆杆轴承	Rocking Bearing	30105008	1
18	轴承套	Bearing cover	10306002112	1	62	滚针轴承K15×18×16.5	Needle Bearing K15×18×16.5	30101031	1
19	滚针轴承HK3012	Needle bearing HK3012	30101026	1	63	斜齿轮	Gear	10302004031	1
20	滚针轴承HK0709	Needle bearing HK0709	30101012	1	64	齿轮调位弹簧	Spring	10303001028	1
21	九齿花垫片	9t Flower Washer	30403092	1	65	弹簧座	Spring Seat	10101011181	1
22	自攻螺钉ST4×14	Screw ST4×14	30202019	9	66	凸型定位垫片	Washer	30403110	1
23	转套外扁卡簧	Outside Ring Spring	30301003	1	67	转子	Armature	10502001056	1
24	转套垫片	Rotary Bush Washer	30403042	1	68	爬电挡圈	Insulation Washer	10101006009	1
25	转套弹簧	Rotary Bush Spring	10303001030	1	69	平垫片8×17×0.5	Washer 8×17×0.5	30403079	2
26	调档O形圈11×2.5	O ring 11×2.5	10102003221	1	70	轴承608	Bearing 608	30104024	1
27	调档铁芯	Steel-shank	10401008009	1	71	轴承衬套	Bearing Cover	10102002003	1
28	调档旋钮	Shift knob	10101007066	1	72	挡风圈	Air Deflector	10101005014	1
29	调档弹簧	Shift Spring	10303001029	1	73	自攻螺钉ST5×50	Screw ST5×50	30202073	2
30	调档方块	Quadrel	10101007064	1	74	定子	Stator	10501001047	1
31	大齿轮	Big gear	10302004030	1	75	装饰片	P.V.C. Film	10101011014	1
32	转套定位钢珠6×10	steel Ball 6×10	30603001	4	76	机壳	Housing	10101001052	1
33	连接转套	Teleflex	10306002016	1	77	右手柄	Right Handle	10101004064	1
34	定位销2.5×12	Locating Pin 2.5×12	30701001	3	78	盘簧	Disc Spring	10303002013	2
35	定位挡圈	Stop Collar	30301001	1	79	电感	Inductance	10604001035	1
36	转套外钢丝卡簧28×1.5	Ring Spring 28×1.5	30303012	1	80	自攻螺钉ST3×10	Screw ST3×10	30202003	4
37	锤杆套定位钢丝卡簧	Ring Spring	30304001	1	81	刷架	Brush Holder	10606001148	2
38	锤杆套	Impact Bolt Sleeve	10306002014	1	82	碳刷	Carbon Brush	10605001187	2
39	锤杆套O形圈16.2×4.5	O Ring 16.2×4.5	10102003002	1	83	开关	Switich	10601001276	1
40	限位套O形圈9.1×3.5	O Ring 9.1×3.5	10102003126	1	84	电容	Capacitance	10603001004	1
41	限位套	Stop Collar	10306002017	1	85	左手柄	Left Handle	10101004066	1
42	转套内钢丝卡簧27.5×2	Rotary Bush inner spring 27.5×2	30304002	1	86	电缆护套	Cord Sleeve	10102001029	1
43	活塞	Piston	10306003002	1	87	电缆压板	Cord Anchor	10101011123	1
44	活塞O形圈15×3	O Ring 15×3	10102003220	1	88	电源线2×0.75	Cord 2×0.75	10602006008	1
Version No.		D			Enable Time		2022.9		

