



Version No.	D	Enable Time	2022.9
-------------	---	-------------	--------

No.	Part Name(Chinese)	Part Name(English)	Code	Qty	No.	Part Name(Chinese)	Part Name(English)	Code	Qty	
1	螺盖	Screw Cover	10801013020	1	45	手轮	Hand Wheel	10801013027	1	
2	支腿	Outrigger	10801013043	3	46	悬吊组件 由19~24\零件组成	Suspension Assembly(consisting accessories of 19~24\P)	10801013040	1	
3	底座	Base Bracket	10801013008	1						
4	微调组件	Trim Assembly	10801013037	1	47	手轮组件 由36~45\零件组成	Hand Wheel Assembly(consisting accessories of 36~45\P)	10801013028	1	
5	动圈	Moving Circle	10801013011	1						
6	对地玻璃	Ground Glass	10801013013	1	48	外壳组件由25~35\零件组成	Housing Assembly(consisting Accessories of 25~35\P)	10801013110	1	
7	压板	Anchor	10801013041	3						
8	转盘	Turntable	10801013046	1						
9	主板	Main Plate	10801013045	1						
10	接线板	Terminal Block	10801013016	1						
11	立柱	Upright Column	10801013019	3						
12	导电O型圈	Conductive O Ring	10801013007	1						
13	一体化重锤	Integrated Hammer	10801013042	1						
14	对地激光器	Ground Laser	10801013014	1						
15	O型圈	O Ring	10801013002	1						
16	配重块	Clump Weight	10801013023	1						
17	摆体	Pendulum	10801013004	1						
18	激光器	Laser	10801013015	5						
19	长轴、螺纹套	Threaded Sleeve for Long Shaft	10801013006	1						
20	下吊耳	Lower Lifting Lug	10801013039	1						
21	短轴、螺纹套	Threaded Sleeve for Short Shaft	10801013012	1						
22	绝缘垫	Insulating Mat	10801013017	3						
23	上吊耳	Upper Lifting Lug	10801013026	1						
24	轴承、中间架	Middle Frame for Bearing	10801013044	1						
25	皮带	Belt	10801013024	1						
26	皮带扣	Belt Buckle	10801013025	2						
27	外壳	Housing	10801013108	1						
28	水泡	Blister	10801013029	1						
29	按键板组件	Key Plate Assembly	10801013003	1						
30	按键贴	Key Sticker	21001001146	1						
31	垂直窗口贴	Vertical Window Paste	21001001147	4						
32	水平玻璃	Horizontal Glass	10801013030	1						
33	水平窗框	Horizontal Window Frame	10801013031	1						
34	电池盒	Battery Box	10801013047	1						
35	电池盒盖	Battery Box Cover	10801013109	1						
36	锁紧板	Lock Plate	10801013032	1						
37	扭簧	Torsion Spring	10801013021	1						
38	扭簧衬套	Torsion Spring Sleeve	10801013022	1						
39	定位簧片	Location Spring	10801013010	1						
40	凸轮	Cam	10801013034	1						
41	微动开关	Microswitch	10801013038	1						
42	锁紧支架	Lock Supporter	10801013033	1						
43	开关盖	Switch Cover	10801013018	1						
44	插片	Illustration	10801013005	1						
Version No.		D			Enable Time			2022.9		